

Align® Adjustable Height Workbench

Installation Instructions

Motorized Base, Hand-Crank Base, Slide Leg Base

Tools Required:

5/32 Hex Key

3/16 Hex Key

9/16 Opened-end Wrench - Glides

7/16 Opened-end Wrench - Casters

#2 Phillips head Screwdriver

Small to medium Hammer or Mallet

Safety Glasses

Electric/Cordless Screw Gun with #2 Phillips Head Bit

Read instructions entirely before assembling

IMPORTANT SAFETY INSTRUCTIONS

WARNING – When using electric appliances, basic precautions should always be followed, including the following:

- Read all the instructions before using the appliance.
- To reduce the risk of injury, close supervision is necessary when an appliance is used near children.
- Do not contact moving parts.
- Only use attachments recommended or sold by the manufacturer.
- Do not use outdoors.
- To disconnect, turn all controls to the off position, then remove plug from outlet.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Unplug from outlet when not in use and before servicing or cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or is dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or electrical or mechanical adjustment.
- This appliance is provided with double insulation and has no serviceable parts. See additional information for Double Insulated Appliances below.

SAVE THESE INSTRUCTIONS

SERVICING OF DOUBLE-INSULATED APPLIANCES

In a double-insulated appliance, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated appliance, nor should a means for grounding be added to the appliance. Servicing of a double-insulated appliance requires extreme care and knowledge of the system, and should be done only by qualified service personnel. Replacement parts for a double-insulated appliance must be identical to those parts in the appliance.



CAUTION:


Make sure benches are positioned with adequate clearance to adjacent objects before operating.


Glide Feet Assembly

All benches

Steps:

- a) Loosen the bolts that hold the Lower Stretcher to the side of the Legs. Lower Stretchers are not included with Slide Leg benches.
- b) Loosely attach Foot to Leg
 Use (4) 5/16 x 2-1/4 long Hex drive bolts
 If rear justified be sure longer end faces the front of the bench
- c) Thread leveling Glides or Casters fully into Foot as shown. Be sure the casters bottom out on foot.
- d) Attach the Foot to the Lower Stretcher as shown Use (2) 5/16 Hex drive bolts and (2) nuts
- e) Repeat steps (a) through (c) for other Leg then tighten all hardware, including all Lower Stretcher hardware.





Steps:

Gusset Style Supports (Refer to Figure A)

- a) Thread bolts into the holes shown
 - Use (3) 5/16 x 5/8 long Hex drive bolts
 - -Keep bolts from bottoming all the way by at least 1/8"
- b) Drop the Support Bracket slots behind the heads of the 3 bolts Set/Push down into place & tighten all bolts. Repeat on opposite side or as needed

Straight Style Supports (Refer to Figure B)

c) Attach Support as shown


Use (2) 5/16 x 5/8 long Hex drive bolts. Repeat on opposite side as needed

Support Rail to any Support Bracket (Refer to Figures A, B & C)

 Insert the end tabs of the Support Rail up from below through the rectangular openings of the Support Brackets then rotate up & push into place

Note: Fastening the Support Rail to the work-surface using all the holes provided is necessary & will secure the Support Rail in position (see page 6).


Hand-Crank Assembly



Steps: (Safety glasses should be worn when installing the Spring-pin)

- a) Slide the open end of Hand-Crank Assembly over Gearbox Shaft as shown
- b) Attach the Support Yoke to the Support Rail
 Use (2) 1/4 X 3/8 long Phillips head bolts & (2) nuts
- c) Turn the Crank Assembly to align hole with hole in the Gear Box Shaft Insert the Spring-Pin into the Installation Tool (*provided*) and use hammer to start Spring Pin Make sure Spring Pin is centered on shaft as the final position

Motorized Bench - Keypad Assembly & Programming



Steps:

- a) Fasten Keypad to Support Rail
 Use (2) #8 x 3/8" Phillips head sheet metal screws Do not over tighten
- b) Plug the Keypad cord into the Control Box Loop any excess wire through the cut-out in the rear of the Support Rail
- c) Hook (3) Wire-Clips over the wire Peal off backing from the Wire-Clips Press into the positions shown



Operating Instructions

Once Base is complete and plugged in;


It is possible to store up to *four heights into memory as follows:

- 1. Using Keypad arrow buttons adjust base to desired height
- 2. *Press and release button labeled U, Followed by either 1 or 2. (This determines which user)*
- 3. Press and release button labeled S.
- 4. With-in two seconds press and release any number button to set into memory
- 5. Repeat as needed or to replace an existing memory setting
- 6. To recall a stored setting press and release button $\boxed{\textbf{U}}$ followed by the user number. Then press and hold the desired memory button until the base stops.

Warning: Do not tamper with any of the electrical control or drive components. Servicing should be performed by qualified service personnel only.

Slide Leg Base Assembly


Start with legs upside down on floor



Center Justified Bases:

Steps:

- a) Loosely attach support channel(s) as shown Use (4) 1/4 x 3/4 long Phillips head bolts and (4) nuts
- b) Move other leg into position and repeat step (a)
- c) Tighten all hardware from steps (a) & (b)



Rear Justified Bases

Steps:

- a) Loosely attach Rear Panel
 Use (3) 5/16 x 5/8 long Hex drive bolts
- b) Move other Leg into position and repeat step (a)
- c) Tighten all hardware from steps (a) & (b)

Slide Leg Base Assembly

Continued

Both Bases Steps:

- d) Refer back to page 1 to install Feet and Rear Panel, then proceed to step (e)
- e) Loosen Knob on Legs enough to allow Inner column to move adjust to desired height and tighten the Knob so that the Bracket fully engages and locks both Columns together.

Caution: Inner Column of Leg will drop down suddenly if released!

Have a second person hold the Foot/Inner Column in place while tightening the Knob.

Once the Knob is tight test it by pulling up on Foot to make sure Columns are locked together. Repeat steps (d) through (e) for other leg

f) Turn Base upright and refer back to page 2 to install the Support Brackets

Offset Caster Foot Assembly


Lower stretcher not shown for clarity

Step:

- a) Remove Lower Stretcher Lower Stretchers are not included with Slide Leg Benches
- a) Attach Offset Foot to Leg Use (4) 5/16 x 3/4 long Hex drive bolts
- b) Thread Casters into Foot as shown. **Be sure the casters bottom out on foot!**



- c) Attach Lower Stretcher
 Use (2) 5/16 x 3/4 long Hex drive bolts & (2) nuts
 Refer to page (1) if needed for Lower Stretcher assembly
- d) Repeat steps (a) through (c) for other Leg then tighten all hardware



Work-Surface Assembly

(Image not shown)

Steps:

- Locate work-surface onto base assembly
 Each side/end overhang should be about 1/2"
 Rear justified bases should be flush to the back of the Rear Panel
 Center justified bases should divide the overhang equally front & rear
- b) Attach Legs and Support Rails/Brackets to work-surface via holes provided Use #10 x 3/4 long Phillips head wood screws
 - Only two screws per Leg are required
 - Use screws in all holes provided on Support Rails/Brackets
- c) Level Base as needed with glides once in final position or location

Align® is a trademark of Lista International Corp. Making Workspace Work® is a trademark of Lista International Corp.

Creation Date Document Number 5-08-2007 MD047A3 Rev. 4

This document is proprietary information of Lista International Corporation. Unauthorized reproduction of any portion of this document is prohibited without written consent of Lista International Corporation. The material in this document is for informational purposes only. It is subject to change without notice.

© 2007 Lista International Corporation 106 Lowland Street Hollistion, MA 01746-2094 E-mail: sales@listaintl.com

All rights reserved

For questions or technical support call 1-800-722-3020

